


# Headlight Adjuster (KG model only)


## Switch Removal

1. Carefully pry out the headlight adjuster switch from the floor console.
- NOTE: Be careful not to damage the switch or floor console when prying out the switch.
2. Disconnect the 4-P connector from the switch.



## Switch Test

1. Remove the switch from the floor console.
2. Measure the resistance between the A and B terminals at 0, 1, 2 and 3 positions by moving the knob.
- Replace the switch if the resistance is not within specifications.



Knob Position	0	1	2	3
Resistance Approx. (kΩ)	1.4	0.5	0.1	0