





Removal


1. Remove the dashlight brightness controller and retractor/fog light switch from the instrument panel.



2. Remove the 5 screws, then remove the instrument panel from the gauge visor.



3. Remove the 4 screws and pull out the gauge assembly from the dashboard, then disconnect the connectors from the gauge assembly.



NOTE: Be carefull not to pinch the wires when installing the gauge assembly.