


System Description

Vacuum Connections


[KX, KS, KZ model]





[KX, KS, KZ model]

Control Box




(cont'd)

System Description


Vacuum Connections (cont'd)

[KF, KG, KW, KB model]





[KY model]




(cont'd)

System Description


Vacuum Connections (cont'd)

[KE model]





[KT model]




(cont'd)

System Description

Vacuum Connections (cont'd)

[KX, KS, KZ model]



- ① MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR
- ② EACV
- ③ VACUUM SWITCH
- ④ CRANKING LEAK SOLENOID VALVE
- ⑤ IDLE BOOST THROTTLE CONTROLLER
- ⑥ A/C IDLE BOOST SOLENOID VALVE
- ⑦ IDLE BOOST SOLENOID VALVE
- ⑧ AIR BLEED VALVE A
- ⑨ POWER VALVE CONTROL SOLENOID VALVE
- ⑩ AIR CONTROL DIAPHRAGM
- ⑪ INTAKE AIR TEMPERATURE (TA) SENSOR
- ⑫ AIR LEAK SOLENOID VALVE
- ⑬ INNER VENT SOLENOID VALVE
- ⑭ AIR VENT SOLENOID VALVE
- ⑮ CANISTER
- ⑯ TWO-WAY VALVE
- ⑰ CHOKE OPENER

- ⑱ VACUUM PISTON CONTROL VALVE
- ⑲ THROTTLE CONTROLLER
- ⑳ THERMOWAX VALVE
- ㉑ SILENCER
- ㉒ AIR SUCTION VALVE
- ㉓ AIR SUCTION CONTROL SOLENOID VALVE
- ㉔ THERMOVALVE
- ㉕ VACUUM PISTON CONTROL SOLENOID VALVE
- ㉖ CHECK VALVE C
- ㉗ AIR CHAMBER
- ㉘ EGR VALVE
- ㉙ EGR CONTROL VALVE
- ㉚ AIR FILTER
- ㉛ PURGE CUT-OFF SOLENOID VALVE
- ㉜ AIR JET CONTROLLER
- ㉝ CATALYTIC CONVERTER