

Gauge Assembly

Component Location Index

SPEED SENSOR

(Located on the transmission case)

Input Test, page 16-11

Replacement, page 16-12

Troubleshooting, page 16-10

GAUGE ASSEMBLY

Gauge Location Index, page 16-4

Bulb Location, page 16-5

Disassembly, page 16-8

Removal, page 16-9

FUEL SENDER UNIT

PARKING BRAKE SWITCH

COOLANT TEMPERATURE GAUGE SENDER

OIL PRESSURE SWITCH

BRAKE FLUID LEVEL SWITCH

