

Fuel Supply System


Fuel Pump

Testing

⚠ WARNING Do not smoke during the test. Keep any open flame away from your work area.

NOTE: Check for a clogged fuel filter and or fuel line before checking fuel pump pressure.

1. Remove the dashboard under cover and the fuel cut-off relay from the fuse box.
2. Connect the No.1 terminal to the No.2 terminal located at the fuse box side of the fuel cut-off relay.



3. Hold a graduated container under the hose. container under the hose.
4. Turn the ignition ON for 60 seconds and measure amount of fuel flow.

Fuel flow should be more than 600 cm³ (20 oz.) in 60 seconds.

- If fuel flow is 600 cm³ (20 oz.), or more in 60 seconds, reconnect cut-off relay and fuel hose.
- If fuel is less than 600 cm³ (20 oz.), check the fuel cut-off relay.

