


Cigarette Lighter

Replacement

1. Remove the floor console.
2. Disconnect the 4-P connector and remove the ashtray light.
3. Disconnect the thermofuse case from the socket end.
4. Remove the ring nut and separate the cigarette lighter socket from the thermal protector.



5. When installing the cigarette lighter, align each lug on the face panel, illumination ring and the cigarette lighter socket with the slot in the hole, then position the bulb case on the thermal protector between the stoppers of the center panel.
6. Make sure that the ground wire, bulb socket and thermofuse case are seated to the cigarette lighter assembly.

Relay Test

1. There should be continuity between the A and B terminals when the battery is connected to the C and D terminals. There should be no continuity when the battery is disconnected.

