





# Transmission Housing/Valve Body


## Removal

### NOTE:

- Clean all parts thoroughly in solvent or carburetor cleaner and dry with compressed air.
- Blow out all passages.
- Mainshaft locknut has left hand thread.

1. Remove the transmission housing and valve body in the following numbered sequence.





NOTE: Remove the mainshaft and countershaft together.

