




Lock-Up Body

Disassembly/Inspection/Reassembly

NOTE:

- Clean all parts thoroughly in solvent or carburetor cleaner and dry with compressed air.
- Blow out all passages.
- Check all valves for free movement, if any fail to slide freely, see Valve Body Repair.
- Coat all parts with ATF before reassembly.



Spring Specifications

Ref. No.	Spring	Standard			
		Wire Dia. mm (in)	O.D. mm (in)	Free Length mm (in)	No. of Coils
①	Torque converter check valve spring	1.1 (0.043)	8.4 (0.331)	36.3 (1.429)	12.5
②	Relief valve spring	0.9 (0.035)	8.4 (0.331)	57.8 (2.276)	20.2