

Gauge Assembly

Speed/Odo/Trip Meter Troubleshooting

NOTE: The numbers in the table show the troubleshooting sequence.

Symptom	Item to be inspected	NS		Speed sensor input test	Speed sensor is not installed correctly	Poor ground	Open circuit in wires or loose or disconnected terminals
		Blown No. 13 (10 A) fuse (in the dash fuse box)	Odo/trip meter				
Speedometer does not operate.		2		1			WHT/BLU
Speedometer operates, but deflection error is great.		2			1		
Odo/trip meter does not operate.			1				
Speedometer and odo/trip meter do not operate.	1	3			2	G101 G151 G701	YEL or WHT/BLU

NOTE:

- The speedometer circuit is built in the main print panel assembly.
- Replace all of the main print panel, the tachometer, the speedometer and the odo/trip meter as a set if one of the above parts is defective.