


System Description

Electrical Connections


FUSES

- ① EFI ECU (10A)*
- ② No. 12 (10A)
- ③ No. 1 (7.5A) (A/T)
- ④ No. 13 (10A)
- ⑤ CLOCK (10A)*

*: In the under-hood relay fuse box



A: BYPASS CONTROL SOLENOID VALVE
B: EGR CONTROL SOLENOID VALVE
C: PURGE CUT-OFF SOLENOID VALVE



TERMINAL LOCATION