





Inspection/Disassembly

1. Remove ring gear and inspect teeth for wear or damage.


CAUTION: Ring gear bolts have left-hand threads.



2. Drive out 5 x 37 mm roll pin with a pin Driver.



3. Remove pinion shaft, pinion gears, side gears, and thrust washers.



4. Wash parts thoroughly in solvent and dry with compressed air. Inspect all parts for wear or damage and replace any that are defective.