


Lubrication Points


No.	LUBRICATION POINTS	LUBRICANT
1	Engine	API Service Grade: SE, SF or SG SAE Viscosity: See chart below
2	Transmission Manual Automatic	API Service Grade: SE or SF SAE Viscosity: See chart below DEXRON® or DEXRON® II Automatic transmission fluid
3	Brake line (Including ALB line for ALB models)	Brake fluid Dot 3 or Dot 4
4	Clutch line	Brake fluid DOT 3
5	Steering gearbox (Power steering)	Honda steering grease P/N 08733—B070E
6	Steering ball joint	Multi-purpose Grease
7	Suspension ball joints	
8	Steering boot	
9	Shift lever pivot (Manual steering)	
10	Steering column bushings	
11	Select lever (Automatic transmission)	
12	Pedal linkage	
13	Brake master cylinder push rod	
14	Trunk hinges	
15	Door hinges upper and lower	
16	Door opening detents	
17	Fuel filler lid	
18	Engine hood hinges	
19	Engine hood latch	
20	Retractable headlight mechanism	
21	Caliper Piston seal Dust seal Caliper pin Piston	Silicone Grease
22	Power steering system	Honda power steering fluid P/N 08208—99961

Recommended Engine Oil
(SE, SF or SG Grade)



Engine oil viscosity for
ambient temperature ranges.

Recommended Manual Transmission Oil
(SE or SF Grade)



Transmission oil viscosity for
ambient temperature ranges.

CAUTION: Used engine oil may cause skin cancer if repeatedly left in contact with the skin for prolonged periods. Although this is unlikely unless you handle used oil on a daily basis, it is still advisable to thoroughly wash your hands with soap and water as soon as possible after handling used oil.

