




# 1st Accumulator/R. Side Cover

## Disassembly/Inspection/Reassembly

### NOTE:

- Clean all parts thoroughly in solvent or carburetor cleaner and dry with compressed air.
- Blow out all passages.
- Coat all parts with ATF before reassembly.



### Spring Specifications

Ref. No.	Spring	Standard			
		Wire Dia. mm (in)	O.D. mm (in)	Free Length mm (in)	No. of Coils
①	One-way ball spring	0.29 (0.011)	4.0 (0.157)	14.0 (0.551)	13
②	1st accumulator spring A	2.8 (0.110)	21.5 (0.846)	56.2 (2.212)	8.9
③	1st accumulator spring B	2.8 (0.110)	9.8 (0.386)	42.0 (1.654)	9.2