




## CYL Sensor Assembly Replacement

### Removal:

1. Remove the CYL sensor assembly from the engine.



### Installation:

1. Install a new O-ring on the sensor housing.
2. Slip the sensor assembly into the position.

NOTE: The lugs on the end of the sensor and its mating grooves in the camshaft end are both offset to eliminate the possibility of installing the sensor 180° out of time.

