





7. Stake the differential carrier at two points.




8. Install the ring gear. Torque bolts to 103 N·m (10.3 kg-m, 74 lb-ft).



CAUTION: Ring gear bolts have left-hand threads.

Oil Seal Removal

1. Remove the differential assembly.
2. Remove the oil seal from the transmission housing.



3. Remove the oil seal from the clutch housing.

