


## A/C Switch

Check for continuity between the terminals according to the table.

| Terminal Position | ④ | ③ | ② | ⑤ | ⑥ | ① |
|-------------------|---|---|---|---|---|---|
| OFF               |   |   |   | ○ | ○ |   |
| ON                | ○ | ○ |   | ○ | ○ |   |
|                   | ○ | ← | ○ |   |   |   |
|                   | ○ | ← | ○ | ← | ○ |   |



## Blower Fan Switch

1. Disconnect the 6P connector from the fan switch.
2. Check for continuity between the terminals of the fan switch according to the table below.

| Terminal Position | 1 | 2 | 4 | 5 | 6 | 3 |
|-------------------|---|---|---|---|---|---|
| OFF               |   |   |   |   |   |   |
| 1                 | ○ | ○ | ○ |   |   |   |
| 2                 | ○ | ○ |   | ○ |   |   |
| 3                 | ○ | ○ |   |   | ○ |   |
| 4                 | ○ | ○ |   |   |   | ○ |

