

Gearshift Selector

Removal/Installation

1. Remove the catalytic converter and exhaust pipe B.
2. Remove the floor heat baffle plate.
3. Remove the gearshift selector mounting nuts.
4. Remove the center console.
5. Disconnect the shift position console switch, S4 switch, shift lock solenoid, and shift indicator light coupler.
6. Remove the lock pin from the cable adjuster, then remove the shift cable.
7. Remove the gearshift selector assembly.
8. Installation is in the reverse order of removal.

