

Gauge Assembly

Gauge/Terminal Locations Index

- **GAUGE ASSEMBLY**

Removal, page 16-9

Disassembly, page 16-8

- **ODOMETER**

Indicates 1 km [1 mile]

at 637 [1,026] revolutions of the speed sensor (4 pulse/rev).

