

Maintenance Schedule

Service at the interval of listed x 1,000 km (or miles) or after that number of months, whichever comes first.							
ITEMS		x 1,000 km	20	40	60	80	100
		x 1,000 miles	12	24	36	48	60
		months	12	24	36	48	60
	Idle speed and idle CO (except KS, KX types)		I	I	I	I	I
	Idle speed and idle CO (KS, KX types)						I
	Valve clearance		I	I	I	I	I
	Alternator drive belt			I		I	
	Timing belt						R
	Water pump						I
■	Engine oil and oil filter	Replace every 10,000 km (6,000 miles) or 6 months					
■	Transmission oil			R		R	
■	Radiator coolant					R ¹	
	Cooling system, hoses and connections			I		I	
	E.G.R. system (for cars using unleaded gasoline)* ²						I
	Secondary air supply system (for carburetor type)* ³						I
	Air cleaner element (dry type)* ⁴		R	R	R	R	R
	Air cleaner element (viscous type)* ⁵			R		R	
	Fuel filter (including aux. filter for carburetor type)			R		R	
	Intake air temp. control system (for carburetor type)						I
	Tank, fuel line and connection			I		I	
	Throttle control system (for carburetor type, except KS, KX types)			I		I	
	Throttle control system (for carburetor type, KS, KX types)						I
	Choke mechanism (for carburetor type, except KS type)			I		I	
	Choke mechanism (for carburetor type, KS type only)				C* ⁸		I
	Choke opener operation (for carburetor type)						I
	Evaporative emission control system* ⁶						I
	Ignition timing and control system (except KS, KX types)			I		I	
	Ignition timing and control system (KS, KX types)						I
	Spark plug (for cars using unleaded gasoline)			R* ⁷		R* ⁷	
	Spark plug (for cars using leaded gasoline)		R	R	R	R	R
	Distributor cap and rotor (except KS, KX types)			I		I	
	Distributor cap and rotor (KS, KX types)						I
	Ignition wiring (except KS, KX types)			I		I	
	Ignition wiring (KS, KX types)						I
	Positive crankcase ventiration valve (except KS, KX types)			I		I	
	Positive crankcase ventiration valve (KS, KX types)						I
	Blow-by filter (for carburetor type)			I		I	
	Brake hoses and lines (including ALB hoses and pipes for ALB models)		I	I	I	I	I
	Brake fluid (including ALB fluid for ALB models)			R		R	
	Front brake discs and calipers		I	I	I	I	I
	Front brake pads	Inspect every 10,000 km (6,000 miles) or 6 months					
	Rear brake discs, calipers and pads			I		I	
	Parking brakes		I	I		I	
	Exhaust pipe and muffler		I	I	I	I	I
	Suspension mounting bolts		I	I	I	I	I
	Front wheel alignment (except 4WS models)		I	I	I	I	I
	Front and rear wheel alignment (for 4WS models)		I	I	I	I	I
	Steering operation, tie rod ends, steering gear box and boots (including center shaft for 4WS models)	except 4WS models	I	I		I	
		for 4WS models	I	I	I	I	I
	ALB high pressure hose (for ALB models)					R	
	ALB operation (for ALB models)		I	I		I	
	Power steering system		I	I	I	I	I
	Power steering pump belt			I		I	
	Catalytic converter heat shield (car equipped with catalytic converter)						I

R—Replace I—Inspect. After inspection, clean, adjust, repair or replace if necessary
C—Clean

■: These service intervals assume routine checking and replenishment has been done, as needed, by the customer.

¹ Thereafter, replace every 2 years or 40,000 km (24,000 miles), whichever comes first.

² Except KQ type.

³ For cars using unleaded gasoline.

⁴ Except European and KQ types.

⁵ For European and KQ types.

⁶ For cars using unleaded gasoline, carburetor type using leaded gasoline and KY type.

⁷ For KS type, replace every 2 years or 40,000 km (24,000 miles) whichever comes first after 30,000 km (18,000 miles).

⁸ Recommended by manufacturer only.



CAUTION: The following items must be serviced more frequently on cars normally used under severe driving conditions. Refer to the chart below for the appropriate maintenance intervals.

Severe driving conditions include:

- A: Repeated short distance driving

B: Driving in dusty conditions

C: Driving in severe, cold weather

D: Driving in areas using road salt or other corrosive materials
- E: Driving on rough and/or muddy roads

F: Towing a trailer

R—Replace

I —Inspect. After inspection, clean, adjust, repair or replace if necessary.

Condition	Maintenance item	Maintenance operation	Interval
A, B, F	Engine oil and oil filter	R	Every 5,000 km (3,000 miles) or 3 months
F	Transmission oil	R	Every 20,000 km (12,000 miles) or 12 months
A, B, D, E, F	Front brake discs and calipers	I	Every 10,000 km (6,000 miles) or 6 months
A, B, D, E, F	Rear brake discs, calipers and pads	I	Every 20,000 km (12,000 miles) or 12 months
B, C, E	Power steering system	I	Every 10,000 km (6,000 miles) or 6 months

CAUTION: Used engine oil may cause skin cancer if repeatedly left in contact with the skin for prolong period. Although this is unlikely unless you handle used oil on a daily basis, it is still advisable to thoroughly wash your hands with soap and water as soon as possible after handling used oil.