

Condenser

Replacement

1. Discharge the refrigerant.
2. Remove the front bumper and engine hood lock (section 20).
3. Disconnect the condenser line and discharge line from the condenser.

CAUTION: Cap the open fittings immediately to keep moisture and dirt out of system.

4. Remove the mounting bolts (2) and condenser.
5. Install in the reverse order of removal, and charge the system (page 15-36) and test performance (page 15-40).

