

Carburetor

Idle Control System


Testing

Idle speed too high in no-load conditions


1. Start the engine and warm up to normal operating temperature (the cooling fan comes on).
2. Disconnect the vacuum hose (4WS: two vacuum hoses) from the idle boost throttle controller and check for vacuum.

There should be no vacuum (4WS: in both hose).

Except 4WS:



4WS:



- If there is no vacuum, check the throttle valve shaft for binding or sticking, and replace the idle boost throttle controller.
- Except 4WS: If there is vacuum, go to troubleshooting (page 6-57, 59).

4WS: If there is vacuum at either hose, go to troubleshooting (#21 hose: page 6-52, 54, outside hose: page 6-57, 59).


Idle speed is rough while the steering wheel is turning (4WS)

1. KX, KS, KZ model: Check the idle speed is above specified in no-load conditions, when the 2P connector on the P/S oil pressure switch is disconnected.

Except KX, KS, KZ model: Disconnect the 2P connector on the P/S oil pressure switch, and connect a jumper wire between the 2 terminals on the wire harness. Then check the idle speed is above specified in no-load conditions.

- If idle speed is as specified in no-load conditions, disconnect the #21 vacuum hose from the idle boost throttle controller and check for vacuum.

There should be vacuum.



- If there is vacuum, check the throttle valve shaft for binding or sticking, and replace the idle boost throttle controller.
- If there is no vacuum, check the vacuum hose for proper connection, cracks, blockage or disconnected hose. If OK, go to troubleshooting (KX, KS, KZ model: page 6-52, Except KX, KS, KZ model: page 6-54).




Idle speed is low with A/C on


1. Disconnect the two vacuum hoses from the idle boost throttle controller and check for vacuum with the A/C on.

There should be vacuum (4WS: in both hoses).

Except 4WS:



4WS:



- If there is vacuum, replace the idle boost throttle controller and recheck.
- 4WS: If there is no vacuum only at the #21 hose, go to troubleshooting (page 6-52, 54).
- If there is no vacuum (4WS: only at the outside hose), go to troubleshooting (page 6-57, 59).

(cont'd)

Carburetor

Idle Control System

[KX, KS, KZ model (4WS)]

Troubleshooting Flow Chart Idle Boost Solenoid Valve

Inspection of Idle Boost Solenoid Valve

Start the engine and warm up to normal operating temperature (the cooling fan comes on).

Disconnect the lower vacuum hose of the solenoid valve from the joint and connect a vacuum pump.

Disconnect the #21 vacuum hose from the vacuum hose manifold, and connect a vacuum gauge.

Is there vacuum?

NO

Turn the ignition switch OFF.

Disconnect the 2P connector on the P/S oil pressure switch.

Turn the ignition switch ON.

(To page 6-53)

YES

Turn the ignition switch OFF.

Disconnect the 4P connector.

Start the engine.

Measure voltage between BRN (+) terminal and BLK (–) terminal.



Is there voltage?

NO

Replace the solenoid valve.


YES

Check the self-diagnosis indicator. If OK, check the input troubleshooting (page 6-18).





(From page 6-52)



(cont'd)

Carburetor

Idle Control System (cont'd)

[Except KX, KS, KZ model (4WS)]

Troubleshooting Flowchart Idle Boost Solenoid Valve

Inspection of Idle Boost Solenoid Valve.

Disconnect the lower vacuum hose of the solenoid valve from the joint and connect a vacuum pump.

Disconnect #21 vacuum hose of the solenoid valve from the vacuum hose manifold and connect a vacuum gauge.

Start the engine.

Apply vacuum.

Is vacuum indicated on the gauge?

NO

Turn steering wheel slowly.

Apply vacuum.

(To page 6-55)

YES

Turn the ignition switch OFF.

Disconnect the connector on the solenoid valve.

Turn the ignition switch ON.

Measure voltage between BRN (+) terminal and BLK (-) terminal on the solenoid valve.



Is there voltage?

YES

- Replace the P/S oil pressure switch.
- Repair the idle boost relay and see air conditioner inspection (section 15).


NO

Replace the solenoid valve.






(From page 6-54)



(cont'd)

Carburetor

Idle Control System (cont'd)





[KX, KS, KZ model (A/C)]

Troubleshooting Flowchart A/C Idle Boost System

Inspection of A/C Idle Boost System

Disconnect the upper vacuum hose of the solenoid valve from the idle boost throttle controller and connect a vacuum gauge.

Start the engine.

Is there vacuum ?

YES

Disconnect the 2P connector near the solenoid valve.

Is there vacuum ?

YES

Replace the solenoid valve.

NO

Inspect the A/C signal (page 6-40).

Turn the A/C switch ON.

Is there vacuum ?

NO

Disconnect the 2P connector near the solenoid valve.

YES

A/C Idle Boost solenoid valve and A/C signal are OK.

Measure voltage between RED (+) terminal and body ground.

NO



Is there battery voltage ?

YES

Disconnect the lower vacuum hose from the solenoid valve and connect a vacuum gauge to the disconnected hose.

(To page 6-58)


(To page 6-58)



(cont'd)

Carburetor


Idle Control System (cont'd)





[Except KX, KS, KZ model (A/C)]


Troubleshooting Flow Chart A/C Idle Boost Solenoid Valve



(cont'd)

Carburetor

Idle Control System (cont'd)






[KX, KS, KZ model]


Idle Boost Throttle Controller Testing

1. Start the engine and warm up to normal operating temperature (the cooling fan comes on).
2. Connect a tachometer.
3. Disconnect the vacuum hose from the idle boost throttle controller and connect a vacuum pump to the controller, then apply vacuum.

Except 4WS:



4WS:



4. Check the engine speed.

Engine speed should be: $1,200 \pm 50 \text{ min}^{-1} \text{ (rpm)}$

Adjust the engine speed, if necessary, by turning the adjusting screw.

(cont'd)

Carburetor

Idle Control System (cont'd)

[KX, KS, KZ model]

Troubleshooting Flowchart A/C Idle Boost Solenoid Valve

