



Existing Tools (Common with Other Models)

5. Engine

●: Carbureted Engine only ○: Fuel-Injected Engine only

Number	Tool Number	Description	Q'ty	Remarks
①	07GAD—PH70100	● Valve Seal Installer	1	
②	07GAF—PH60100	Piston Base Head	1	
③	07GAF—PH60200	● Pilot Collar	1	
④	07GAF—PH60300	Piston Pin Base Insert	1	
⑤	07GAF—PH70100	○ Pilot Collar	1	
⑥	07JAB—0010000	Crank Pulley Holder Set	1	for crankshaft pulley bolt
⑥-1	07JAA—0010200	Socket Wrench, 19 mm	(1)	Component tools
⑥-2	07JAB—0010100	Pulley Holder Attachment	(1)	
⑥-3	07JAB—0010200	Handle	(1)	
⑦	07KAK—SJ40100	Engine Tilt Hanger Set	1	
⑧	07406—0030000	Oil Pressure Gauge Adaptor	1	
⑨	07743—0020000	Adjustable Valve Guide Driver	1	
⑩	07746—0010400	Attachment 52 x 55 mm	1	
⑪	07749—0010000	Driver	1	
⑫	07757—PJ10100	Valve Spring Compressor Attachment	1	
⑬	07757—0010000	Valve Spring Compressor	1	
⑭	07912—6110001	Oil Filter Socket	1	
⑮	07924—PD20003	Ring Gear Holder	1	
⑯	07942—SA50000	● Valve Guide Driver, 7.0 mm	1	may also be used 07942—8230000
⑰	07942—6570100	Valve Guide Driver, 6.6 mm	1	may also be used 07942—6110000
⑱	07943—6890100	Valve Guide Driver Attachment	1	
⑲	07947—SB00100	Seal Driver	1	
⑳	07948—SB00101	Driver Attachment	1	
㉑	07973—PE00302	Adj. Piston Pin Driver	1	may also be used 07973—PE00301
㉒	07973—6570002	Piston Pin Dis/Assembly Tool Set	1	
㉒-1	07973—6570500	Piston Base	(1)	Component tools
㉒-2	07973—6570600	Piston Base Spring	(1)	
㉓	07984—SA50000	● Valve Guide Reamer, 7.0 mm	1	may also be used 07984—6890101
㉔	07984—6110000	Valve Guide Reamer, 6.6 mm	1	may also be used 07984—6570101

6. Fuel and Emissions

●: Carbureted Engine only ○: Fuel-Injected Engine only

Number	Tool Number	Description	Q'ty	Remarks
①	07GMJ—ML80100	Inspection Adaptor	1	
②	07HAZ—PJ70000	● ECU Check Adaptor A	1	
③	07HAZ—PJ7010A	● ECU Check Adaptor B	1	
④	07401—0010000	● Float Level Gauge	1	
⑤	07406—0040001	○ Fuel Pressure Gauge	1	
⑥	07411—0020000	Digital Circuit Tester	1	
⑦	07614—0050100	● Fuel Line Clamp	1	
⑧	07999—PD6000A	○ System Checker Harness	1	

Special Tools

Existing Tools (Common with Other Models)

7. Clutch

Number	Tool Number	Description	Q'ty	Remarks
①	07JAF—PM7011A	Clutch Alignment Disc	1	
②	07LAF—PT00110	Clutch Alignment Shaft	1	
③	07924—PD20003 or 07924—PD20002	Ring Gear Holder	1	
④	07936—3710100	Handle	1	

8. Manual Transmission

Number	Tool Number	Description	Q'ty	Remarks
①	07GAJ—PG20102	Mainshaft Inspection Tool	1	
①-1	07GAJ—PG20110	Shaft Holder	(1)	
①-2	07GAJ—PG20130	Base	(1)	
②*	07HAJ—PK40201	Preload Inspection Tool	1	
③	07JAC—PH80000	Adjustable Bearing Remover Set	1	
③-1	07JAC—PH80100	Bearing Remover Attachment	(1)	
③-2	07JAC—PH80200	Remover Hundle Assembly	(1)	
③-3	07741—0010201	Remover Weight	(1)	
④*	07JAD—PH80101	Seal Driver Attachment	1	
⑤*	07JAD—PH80400	Pilot Driver 28 x 30 mm	1	
⑥	07JAD—SH30100	Oil Seal Driver	1	
⑦*	07JAF—SH20200	Ball Joint Remover Base	1	
⑧	07LAD—PW50600	Bearing Driver Attachment 40/50 mm	1	New tool
⑨	07744—0010400	Pin Driver 5 mm	1	
⑩	07746—0010300	Attachment 42 x 47 mm	1	
⑪	07746—0010400	Attachment 52 x 55 mm	1	
⑫	07746—0010500	Attachment 62 x 68 mm	1	
⑬*	07746—0010600	Attachment 72 x 75 mm	1	
⑭*	07746—0041100	Pilot Driver 28 mm	1	
⑮	00749—0010000	Driver	1	
⑯*	07944—SA00000	Pin Driver 4 mm	1	
⑰*	07947—SD90100	Seal Driver Attachment	1	
⑱	07979—PJ40001	Magnet Stand Base	1	

*: For differential



9. Automatic Transmission

Number	Tool Number	Description	Q'ty	Remarks
①	07GAB—PF50100	Mainshaft Holder	1	
②	07GAC—PF40210	Bearing Remover Attachment	1	
③*	07GAD—PG20100	Pin Driver 5 mm	1	
④*	07GAD—PG40100	Oil Seal Driver	1	
⑤	07GAE—PG40001	Clutch Spring Compressor Set	1	
⑤-1	07HAE—PL50100 or 07LAE—PX40100	Clutch Spring Compressor Attachment	(1)	
⑤-2	07GAE—PG40200	Clutch Spring Compressor Bolt Assembly	(1)	
⑤-3	07960—6120101 or 07960—6120100	Clutch Spring Compressor Attachment	(1)	
⑥*	07GAJ—PG20200	Preload Inspection Tool	1	
⑦	07GMJ—ML80100	Test Harness	1	
⑧	07HAC—PK40100 or 07GAC—PG40102	Housing Puller	1	
⑨	07HAF—PK40100	Gear Installer	1	
⑩	07HAJ—PK40100	A/T Throttle Gauge	1	
⑪*	07JAD—PH80400	Pilot Driver 28 x 30 mm	1	
⑫*	07LAD—PW50600	Bearing Driver Attachment	1	
⑬	07406—0020003	A/T Oil Pressure Gauge Set	1	
⑬-1	08406—0020201	A/T Oil Pressure Gauge Replacement Hose	(1)	
⑭	07406—0070000	Low Pressure Gauge	1	
⑮	07746—0010500	Attachment 62 x 68 mm	1	
⑮*	07746—0030100	Driver C	1	
⑰*	07749—0010000	Driver A	1	
⑱	07936—6340000	Bearing Remover Set	1	
⑲*	07947—6110501	Oil Seal Driver	1	
⑳	07947—6340201	Oil Seal Driver	1	
㉑	07947—6340500	Driver Attachment E	1	
㉒	07998—SA50000	Throttle Pedal Weight Set 1.5 kg	1	
㉓	07998—SA50100	Throttle Pedal Weight Main Adopter 1.0 kg	1	
㉔	07998—SA50200	Throttle Pedal Weight Sub Adopter 0.5 kg	1	

Special Tools

Existing Tools (Common with Other Models)

10. Driveshaft

Number	Tool Number	Description	Q'ty	Remarks
①	07GAD—SE00100	Oil Seal Driver Attachment	1	
②	07746—0010400	Attachment, 52 x 55 mm	1	
③	07746—0010500	Attachment, 62 x 68 mm	1	
④	07746—0040900	Pilot, 40 mm	1	
⑤	07749—0010000	Driver	1	
⑥	07947—SD90200	Oil Seal Driver	1	
⑦	07965—SD90100	Support Base	1	
⑧	07965—SD90200	Support Collar	1	

11. Power Steering (2WS/4WS Community)

Number	Tool Number	Description	Q'ty	Remarks
①	07GAG—SD40000	P/S Tool Kit	1	
①-1	07GAG—SD40100	Piston Seal Ring Guide	(1)	Component tools
①-2	07GAG—SD40200	Piston Seal Sizing Tool	(1)	
①-3	07GAG—SD40300	Cylinder End Seal Slider	(1)	
①-4	07GAG—SD40400	End Seal Guide	(1)	
①-5	07GAG—SD40600	Tool Box	(1)	
②	07GAK—SE00100	P/S Pressure Gauge Adaptor Set	1	
②-1	07GAK—SE00110	P/S Joint Adaptor (Pump)	(1)	Component tools
②-2	07GAK—SE00120	P/S Joint Adaptor (Hose)	(1)	
③	07406—0010101	Bypass Tube Joint	1	
④	07406—0010200	P/S Pressure Gauge Set	1	
④-1	07406—0010300	Pressure Control Valve	(1)	Component tools
④-2	07406—0010400	Pressure Gauge	(1)	
⑤	07725—0030000	Pulley Holder	1	
⑥	07746—0010300	Attachment, 42 x 47 mm	1	
⑦	07749—0010000	Driver	1	
⑧	07916—SA50001	40 mm Lock Nut Wrench	1	
⑨	07941—6920003	Ball Joint Remover	1	
⑩	07947—6340300	Driver Attachment	1	
⑪	07953—7190000	Collar Driver	1	
⑫	07974—SA50600	Pinion Seal Guide	1	



11. Power Steering (4WS only)

Number	Tool Number	Description	Q'ty	Remarks
①	07HAA—SF10100	Lock Nut Socket 36 x 41 mm	1	Component tools
②	07HAG—SF10000	4WS Tool Kit	1	
②-1	07HAG—SF10100	Piston Seal Ring Guide	(1)	
②-2	07HAG—SF10200	Piston Seal Ring Sizing Tool	(1)	
②-3	07HAG—SF10300	Pinion Seal Ring Guide	(1)	
②-4	07HAG—SF10400	Pinion Seal Sizing Tool	(1)	
②-5	07HAG—SF10500	Driver Seal Ring Guide	(1)	
②-6	07HAG—SF10600	Tool Box	(1)	
③	07HAJ—SF10100	Rack Adjuster Gauge Holder Set	1	
④	07HAJ—SF10201	Rear Adjuster Center Lock Pin	1	
⑤	07HAJ—SF10300	Stroke Rod Holder Set	1	
⑥	07HAJ—SF10400	Inspection Adaptor	1	
⑦	07703—0010101	Torx Driver Bit T40	1	
⑧	07746—0010700	Attachment 24 x 26 mm	1	

12. Suspension

Number	Tool Number	Description	Q'ty	Remarks
①	07GAE—SE00101	Spring Compressor	1	may also be used 07GAE—SE00100
②	07GAF—SD40700	Hub Dis/Assembly Base	2	
③	07GAF—SE00100	Hub Assembly Pin	1	
④	07GAF—SE00200	Front Assembly Driver Attachment	1	
⑤	07GAF—SE00401	Front Hub Base	1	
⑥	07GAG—SD40700	Ball Joint Boot Clip Installation Guide	1	
⑦	07GAK—0010100	Wheel Alignment Gauge Attachment	1	
⑧	07HAD—SF10100	Hub Bearing Driver	1	
⑨	07HAF—SF10100	Ball Joint Dis/Assembly Tool Kit	1	
⑨-1	07HAF—SF10110	Ball Joint Remover Base	(1)	
⑨-2	07HAF—SF10120	Ball Joint Installer Base	(1)	
⑨-3	07HAF—SF10130	Ball Joint Remover/Installer	(1)	
⑩	07HAF—SF10200	Bearing Supporting Attachment	1	
⑪	07HAJ—SF10201	Rear Steering Center Lock Pin	1	
⑫	07HGJ—0010000	Toe Inspection Gauge Set	1	
⑬	07703—0010100	Torx Driver Bit T40	1	Component tools
⑭	07746—0010400	Attachment, 52 x 55 mm	1	
⑮	07746—0010500	Attachment, 62 x 68 mm	1	
⑯	07749—0010000	Driver	1	
⑰	07941—6920003	Ball Joint Remover	1	
⑱	07965—SB00000	Ball Joint Dis/Assembly Tool Set	1	
⑱-1	07965—SB00100	Ball Joint Remover Base	(1)	
⑱-2	07965—SB00200	Ball Joint Installer Base	(1)	
⑱-3	07965—SB00300	Ball Joint Remover/Installer	(1)	
⑲	07965—SD90100	Supporting Base	1	
⑳	07965—6920201	Front Hub Dis/Assembly Tool, B	1	Component tools
㉑	07974—SA50700	Ball Joint Boot Clip Installation Guide	1	
㉒	07974—SA50800	Ball Joint Boot Clip Installation Guide	1	

Special Tools

Existing Tools (Common with Other Models)

13. Brakes (Conventional Brakes Community)

Number	Tool Number	Description	Q'ty	Remarks
①	07GAG—SE00100	Rod Bolt Adjustment Gauge	1	
②	07HAE—SG00100	Brake Spring Compressor	1	
③	07404—5790300	Vacuum Gauge	1	
④	07406—5790200	Pressure Gauge	2	
⑤	07410—5790100	Pressure Gauge Attachment	2	
⑥	07510—6340100	Pressure Gauge Joint Pipe	2	
⑦	07510—6340300	Vacuum Joint Tube A	1	
⑧	07749—0010000	Driver	1	
⑨	07914—SA50000	Snap Ring Pliers	1	
⑩	07921—0010001	Flare Nut Wrench	1	
⑪	07947—6890300	Driver Attachment, C	1	

13. Brakes (ALB only)

Number	Tool Number	Description	Q'ty	Remarks
①	07HAJ—SG00300	ALB Checker Adaptor	1	
②	07HAK—SG00110	Pressure Gauge Joint Pipe	1	
③	07404—5790300	Vacuum Gauge	1	
④	07406—5790200	Pressure Gauge	2	
⑤	07410—5790100	Pressure Gauge Attachment	2	
⑥	07410—5790500	Tube Joint Adaptor	1	
⑦	07508—SB00000	ALB Checker	1	
⑧	07510—6340100	Pressure Gauge Joint Pipe	1	
⑨	07510—6340300	Vacuum Joint Tube A	1	
⑩	07907—SB00000	ALB-Wrench	1	
⑪	07921—0010001	Flare Nut Wrench	1	
⑫	07965—5790300	Cup Guide	1	

14. Boby

Number	Tool Number	Description	Q'ty	Remarks
①	07GAZ—SE30100	Torsion Rod Assembly Tool	1	

15. Heater and Air Conditioner

Number	Tool Number	Description	Q'ty	Remarks
①	07HAF—SF10300	Seal Seat Remover	1	
②	07HAF—SF10400	Seal Remover/Installer	1	

16. Electrical

Number	Tool Number	Description	Q'ty	Remarks
①	07GAC—SE00200	Fuel Sender Wrench	1	