


# Gauge Assembly

## Replacement

1. Disconnect the 3-P connector from the speed sensor.
2. Remove the mounting bolts and the speed sensor from the power steering speed sensor.



3. Install in the reverse order of removal.

**NOTE:** Be careful not to loose the joint shaft, for it is a tiny part.