

Fluid Level

Checking/Changing



Checking

NOTE: Check fluid level after the engine has warmed up to normal operating temperature.

1. Park the car on level ground, stop the engine.
2. Remove the air-inlet.
3. Pull the transmission dipstick and check the level of fluid immediately after the engine is stopped within one minute.

NOTE: Transmission dipstick has yellow handle.

4. If the level is at, or below, the low mark, add DEXRON-II type automatic transmission fluid.



Changing

1. Bring the transmission up to operating temperature by driving the car. Park the car on level ground, turn the engine off, then remove drain plug.
2. Reinstall the drain plug with a new washer, then refill the transmission to the full mark on the dipstick.

Automatic transmission Fluid Capacity:

2.8 ℓ (3.0 U.S. qts. 2.5 Imp. qt) at change

6.2 ℓ (6.6 U.S. qts. 5.5 Imp. qt) after overhaul