


Oil Seal Installation

1. Install the oil seal in the transmission housing.



2. Drive the oil seal into the torque converter housing.

