


Back-up Light Switch

Replacement

NOTE: Check the switch.

1. Disconnect the back-up light switch wire connectors.
2. Remove the back-up light switch.




3. Install the new washer and back-up light switch.

Transmission Assembly




Installation

1. Attach the 14 mm dowel pin to the transmission.
2. Support the transmission with a jack or by some other means.
3. Tighten the transmission mount bolt on the engine side.



4. Tighten the transmission mount bolt on the transmission side.



(cont'd)