




Oil Seal Installation

1. Drive the oil seal in until it's flush with the transmission housing using the special tools.



2. Install the oil seal in the clutch housing using the special tools.

